

Programmable Digital Timer Instructions



Thank you for buying our product. The following instructions will help you program this timer.

CAUTION:

1. Installation must be according to wire diagram. See the back of the unit.
2. Press RESET button before use.
3. Recharge the battery when no indication appears in the display.

BUTTON DEFINITION

Clock: Current time setting or show current time.

Timer: Press this button to enter program mode. There are 8 on / 8 off programs lines.

Day: Sets the day of the week.

Hour: Sets the hour button. 24 HOUR MILITARY TIME

Min: Set the minute button.

Manual: ON/AUTO/OFF select mode.

RESET Cancel all settings. It is the recessed button next to the circled P with a X through it.

Use ballpoint pen to push it.

ON: RED LED indicator lamp . LED light on when the internal switch is turned on.

I: SET CURRENT TIME AND DAY

1. Press CLOCK and DAY buttons together. Pulse the DAY Button to advance to current day.
2. Press CLOCK and HOUR buttons together. Pulse the HOUR button to advance to current Hour.
3. Press CLOCK and MIN buttons together. Pulse the MIN button to advance to current time.
4. After setting the day and time, the seconds will automatically reset.

II: SET PROGRAMS

1. Press TIMER button once "1ON" will appear at the left side of display. This is the "1" program that you desire the device to turn on.
2. Press DAY button to select the program period.
3. Press HOUR button to set hour.

4. Press MIN button to set minute.

5. After setting the "1ON" program. then press TIMER button again "1OFF" will appear. this is the "1" program that you desire the device to turn off.

6. Repeat the same procedure until "1OFF" program is set.

7. Your timer gives you up to 8 different ON and 8 different OFF per program period. You can use all 8 settings per period, or as few as required.

III: REVIEW SET PROGRAMS

1. Pulse TIMER button to advance displayed to each subsequent ON or OFF settings.
2. To make changes follow instructions under " SET PROGRAMS".
3. Push CLOCK button to return to current time display.

IV: MANUAL OVERRIDE BUTTON

1. Pulse MANUAL button to select **ON/AUTO/OFF** mode.
2. ON mode turns on the device and it will stay on until manually turned to OFF or AUTO. OFF mode turns off the device. and it will stay OFF until manually turned to ON or AUTO. (YOU CAN USE THIS TO TURN ON THE GENERATOR)
3. In AUTO mode. It will turn ON or turn OFF according to the programs for which the timer is set.
4. MANUAL OVERRIDE FEATURE: Turn device ON if already OFF or OFF if already ON. Timer automatically resumes program on next programmed cycle. (From ON to AUTO mode, it will stay on until the next programmed OFF time). (From OFF to AUTO mode, it will stay OFF until next programmed ON time)